



# APPLYING EDGING

Gluing hardwood edging to plywood is not easy. It's tricky to keep the edging from slipping while tightening down the clamps. So to help hold the edging in place, make some clamping blocks.

These blocks have a shallow, wide groove on one side that's sized to just fit over the edging and plywood and holds the edging flush with the plywood.

To prevent the blocks from getting glued to the work piece, apply wax to the surface of the blocks (or line with clingwrap) before using them.

